







- 5. Sales exclusive agent sales right have been prosec. Package information.

 I. Forming polyfosm for the post package

 Ledder strong polyfosm are used for safe package during transportation.

 Code strong polyfosm are used for safe package during transportation.

 Production ledder are used for safe package during transportation.

 Production lead time

 2.55–50 days after received deposit.

 Normal on production line production lead time is 15days after received deposit.